

RF ID Reader

RF ID Reader

- MIFARE® USB
- Temic USB
- EM-ARE

-
-
-
-
-
- 12

control__ For
control__ For elecator
__ For

RF ID Reader

	1	
	1	
	1	
CARD	5	
	1	
software	1	