

PY-8505-F

□□□



A MIFARE® USB □□□□□□□□□□

B USB □□□□□□□□□□

C EM □□□□□□□□□□□□□□

□□□□□□

Lock	1 pc	For guest room
Encoder	1pc	For authorize card, when need software management
Switch	1 pc	To gain power for the room(optional software managed)
Card	5 pc	To open doors
Date gather	1pc	To collect entrance information
Software	1 pc	Free, permanent , packed with Encoder

□□□□ □□□

□□□□

□□

□□□□□□□□□□□□□□□□□□

□□□□□□□

12□□□□

□□□□□□ □□□□□□

Access control	For common area, or main doors etc. same software, same card
Elevator control	For elecator. same software, same card
Room status	For guest room, come with door bell