

## Punch Card Время работы машины PY-S880

### Параметры:

Карта Вместимость	10000
Емкость транзакции	5+0000
Аппаратная платформа	ЗЭМ510
связь	RS232 / 485, TCP / IP, USB-хост
Стандартные функции	Рабочий код, SMS, DLST, Запланированный звонок, запрос самообслуживания, автоматический переключатель состояния, вход T9, идентификатор фотографии, камера, веб-сервер
Интерфейс управления доступом для	3й Электронный замок, дверной датчик, кнопка выхода, сигнализация, дверной звонок
Сигнал Виганда	Вход & Вывод
Дополнительные функции	ID / IC, Wi-Fi, GPRS
дисплей	3,5-дюймовый TFT-экран
Источник питания	DC 12V 1.5A
Рабочая Температура	0 °C - 45 °C
Рабочая влажность	20% -80%

### [Идентификационная карточка RF](#)





### Packing list

#### For time attendance device:

In addition to the device, this package includes the following items:

- Printed documentation and software CD
- AC adapter
- Accessory package
- ID card (only for device with RFID function)

#### For access control device:

In addition to the device, this package includes the following items:

- Printed documentation and software CD
- Accessory package
- ID card (only for the device with RFID function)

Contents may vary depending on the device configuration.

The information contained herein is subject to change without notice.

